Air Cleaner 2

Based on the Corsi-Rosenthal Box*



18 Inch (40cm) Circular Fan 20x25 Inch filters

Metric bolt construction using 3030 t-slot framing system

Scalable & modular

Variety of materials choices

Kit assembly

Capable of >1000m3/hr flowrate

Anti tamper features


Prefilter options

Timer or IoT plug options



20 Inch (50cm) Box Fan 20x20 Inch Filters

Exploded view




Flat pack

Sub assemblies







Fan bottom plate sub assembly




Corner sub assembly






Base plate sub assembly



Cable management

PG9 gland



OPTIONS

<u>High Flow – Recommended</u>

18 Inch (45cm) 100-120w Cage Fan 20x25 Inch filters*

Sizes



Low Noise, Small Footprint - Lowest Flow

14 Inch (35cm) 50-80w Cage Fan 16x25 Inch filters




US / Canada Optimised DIY Spec


20 Inch (50cm) 60w Box Fan 20x20 Inch filters

Basic box

Example:



Basic box mount



• Cage fan pinned by leg bolts & spacers






Box fan secured by 2x zip ties •




Material specifications




Lowest Cost:

Tapped Threads




Most Robust:

Elastic T-Slot Nuts



Anti tamper



<u>Prefilter</u>

G3 or 4Oz fire retardant polyester wadding
 + Fibreglass insect mesh






Aesthetic covers

Custom vinyl print or painted panel



Long M6 for minimum 50mm gap*




1-4 filter construction

Dummy filter blank plate example






Filter clamp



2" (48mm) deep filters




EPA filter adapter example

IKEA STARKVIND E12 EN1822





Commercial plate fan





Fan and filter specifications

FANS – General specifications

20 Inch Box fans

- Speed adjustable models via side mounted dial.
- Max 70w rating advised for noise

18 Inch Cage Fans

- · Legs removed
- Single speed (rear controls inaccessible)
- Max 120w rating advised for noise
- 500mm to edges of cage grill

14 Inch Cage Fans

- Legs removed
- Single speed (rear controls inaccessible)
- Max 70w rating advised for noise
- 385mm to edges of cage grill

High Efficiency Commercial Plate fans

20 Inch Filters: HPA315/4-1A, HPA400/6-1A 16 Inch Filters: HPA250/4-1A

- Pre-wired
- Speed switch / controller
- Outlet safety grill with 4mm or less gap

FILTERS – General specifications

Panel types

- ISO F7/F8 ePM1 50% or higher
- MERV 13 or 14
- EPA 11, EPA 12
- Use filter with ASHRAE Standard 52.2, EN1822 or GB/T 14295 rating where appropriate for locality.

Panel sizes

ISO

- 490x592mm (20x24 equivalent)
- 490x620mm (20x25 equivalent)
- 24 or 48mm deep

ASHRAE

- 20x25 Inch
- 20x24 Inch
- 20x20 Inch
- 1 or 2 Inch deep (increase clamp bolt length for 2")

Standard retail replacement filters with custom adapter

E.g. IKEA STARKVIND EPA 12

Other sizes possible with custom adapter plates.

Recommended

20 Inch Box Fans

US/CA Default box fan: Lasko 3733

EU Default box fan: Sichler VT-241.B

18 Inch Cage Fans

High quality & flow: NETTA sickle blade
High quality & efficient: Hydor Typhoon
Budget & low noise: Prem-I-air EH0522

14 Inch Cage Fans

Recommendation list WIP, check dimensions of cage and adjust mount plate accordingly.

Filters

Retail Available: Filtrete MPR 1900, 2200
Commercial: EN1822 rated EPA 11/12

Pre filters

G2/G3 or 40z fire retardant polyester wadding prefilter

+ Fibreglass insect mesh

USE & MAINTENANCE

Filter replacement

Replacement schedule guide*

Every 6 months if used 12 hrs/day

Every 3-6 months 24 hrs/day

OR

Condition Monitoring Options

PM2.5 sensor

RPM by blade pass frequency on tablet/phone spectrogram app

+

Power consumption & voltage

SPL noise measure at 1m from edge of cart. E.g. NIOSH phone app or type 2 SPL meter

Air velocity meter (E.g. Testo 405i) sweep average velocity across filter inlet.

I/O Automation



Timer inline socket

OR

IoT WIFI inline plug socket

Fan service schedule


Clean fan cage and blades at every filter change.


Re oil fan motor bearing every second filter change.

Placement

3 Filters 1 blank plate

4 Filters





Avoid corners

